

(9) List of spare parts

Item	HEYLO Art. No.	Description
1	1400216	Ventilator complete
2	1262400	Protective grille - ventilator
3	1262403	Protective grille - exhaust side
4	1400310	Condenser 3 μ F, 400 V
5	1400526	Round blower insert 18 kW
6	1300300	Insulation jacket for heating insert
7	1440013	Contacteur (18 A)
8	1440014	Mini-contacteur (22 A)
9	1440400	Control fuse 6.3 A, 230 V
10	1440408	Miniature unit circuit breaker
11	1450912	Extension housing for RT
12	1450916	Cap for room thermostat connection
13	1451002	Socket insert
14	1660020	Unit base
15	1430017	Safety temperature limiter 100 deg. C
16	1430123	Thermostat for hose protection
17	1660021	Formed handle
18	1309287	Exhaust connector
19	1450282	Power cable with plug 32 A
20	1430124	Thermostat for HT display
21	1440043	Signal lamp red (STB)
22	1440044	Signal lamp yellow (Temp.)
23	1330005	Anti-interference capacitor
24	1330006	Speed controller
25	1330007	Adjustment potentiometer for speed
26	1309290	Operating hours counter
27	1440740	Toggle switch is lit green

